

**Cabinet catch No. 208**

Article	Art. No.	Finishes
Cabinet catches <b>straight</b> 30 mm = 1 <sup>3</sup> / <sub>16</sub> "	208	Z = polished and lacquered
with 5 mm = 13/64" nose	208-5	N = nickel plated
with 8 mm = 5/16" nose	208-8	M = brass plated and lacquered
Strike, small	208-S	
Example for ordering: 500 pieces 208-5/Z		



Zinc die-cast  
Screw:  
oval head  $\phi$  3 mm = 1/8"  
Package: 100 pieces

**Catches Nos. 207, 210**

Article	Art. No.	Finish
Catch 45 mm = 1 <sup>3</sup> / <sub>4</sub> "	210	Z = polished and lacquered
Catch 60 mm = 2 <sup>3</sup> / <sub>8</sub> "	207	
Catch Stuttgart	207-St	
Distance pieces 8 mm = 5/16"	207-8	
10 mm = 25/64"	207-10	
13 mm = 33/64"	207-13	
15 mm = 19/32"	207-15	
17 mm = 43/64"	207-17	
19 mm = 3/4"	207-19	
Adjusting parts 4 mm = 5/32"	207-A4	
8 mm = 5/16"	207-A8	
Lay-on plates	207-Pa	
Strike	207-S	
Example for ordering: 500 pieces 207, 500 pieces 207-10, 500 pieces 207-S		



Zinc die-cast  
Screws:  
oval head  $\phi$  3 mm = 1/8"  
Package: 100 pieces  
Positioning tool: 207-E

**Star nails No. 211**

Article	Art. No.	Length	
		mm	in.
Star nails	211-20	20	25/32"
	-25	25	1"
	-29	29	1 1/8"
	-33	33	1 3/16"
	-38	38	1 1/2"
	-44	44	1 11/64"
	-50	50	2"
	-60	60	2 3/8"
Example for ordering: 20 000 pieces 211-50			

Fine zinc alloy,  
suitable for planing  
Package: 500 pieces

